

57" Retractable Banner Stand


INSTRUCTIONS

• Maximum width: 57"

• Maximum height: 78" / Height is also adjustable.

*No tools required
Easy set up in minutes.*


1 Prepare banner to be within 57" wide.




2 Place 1/2" of banner into top clip to secure banner into top bar.

Release clip and slide bar (folded side up) into Top Bar.


Top Bar - Side View



3 Peel off adhesive strip from base. Adhere the bottom of the banner to the strip. Use clear tape on the front and back for a more secure hold.



WARNING! Do not pull until AFTER Banner has been attached to the adhesive strip.



4

